

# Assembly Instructions: Bedworks *Bookcase Headboard*

HARDWARE	
6	Barrel Nuts
4	Allen Bolts
1	Allen Wrench
4	Long Dowels
4	Short Dowels
2	15" Threaded Rods
2	Allen Bolt Caps

